

SVEN[®]
YOU WANT - WE CAN

External HDD Enclosure

USER'S MANUAL



SE-205E

www.sven.fi

Congratulations on your purchase of the Sven external HDD enclosure!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

© 2014. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

UNPACKING

Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.

SAFETY PRECAUTIONS

- Do not put foreign objects inside the holes of the device.
- Protect the device from humidity, dust and heating.
- Do not use gasoline, alcohol or other solvents when cleaning, since they may damage the surface. Clean the device with dry soft cloth only.

- For extra protection during a thunderstorm, disconnect the device from a USB port and switch off your computer.

PACKAGE CONTENTS

- Aluminium case – 1 pc
- Screws & screwdriver – 1 set
- Set of cables: USB cable (USB to mini USB), USB power cable, eSATA cable – 1 pc
- Bag – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES

- Installation tools included
- eSATA high-speed interface
- Alluminium case for shock protection and heat removal
- Power and HDD activity LEDs
- Easy disk insertion, additional disk fixation
- «Leather» case and USB cables included

SYSTEM REQUIREMENTS

- PC/laptop with a USB port
- OS Windows XP/Vista/7/8

INSTALLATION AND OPERATION GUIDE

Hardware Installation

- Open the case cover. Insert the disk tightly and close the cover using the screwdriver and screws (included) (Fig. 1).
- When connecting via USB 2.0 interface, use the included USB cable (USB to mini USB). Insert the USB cable into a USB port on your computer (Fig. 2, a).
- When connecting via eSATA interface, use the included USB cable (Fig. 2, b). The installation is complete.

Software Installation

- Software installation is not required for Windows XP/Vista/7/8 OS. During the first connection to a USB 2.0 or eSATA port, the system will detect the device and install the necessary drivers automatically. After the HDD is detected, a Safely Remove Device icon will appear on the taskbar in the bottom right corner of your screen.

Windows XP/Vista/7/8 Partitioning and Formatting

- To partition and format your HDD, please refer to relative documents. We strongly recommend that this should be done by qualified experts.

- If you still decide to do it yourself, connect your external HDD to your PC. Right click on the My Computer icon, select Manage, then Disc Management, and select your external HDD for partitioning and formatting.

Attention! Please be careful in selecting the disk to be partitioned and formatted!




Fig. 1. Hardware installation diagram




Fig. 2. Connection diagrams: a) via USB 2.0; b) via eSATA

LED light

LED Light	Color Status
Red Light	Powered, but inactive
Green Light	Reading or writing data

TROUBLESHOOTING

In case of malfunction, make sure that your HDD is properly inserted into the external HDD enclosure, that the USB cable is connected to a PC or laptop USB port and the PC or laptop is on.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Form factor, inch	2.5
Interface	external – USB 2.0/eSATA, internal – SATA
OS required	Windows XP/Vista/7/8
USB cable length, m	0.8
eSATA cable length, m	1.0
Dimensions, mm	135 × 78 × 18
Weight (without HDD), g	91

Notes:

- *Technical specifications given in this table are supplemental information and cannot give occasion to claims.*
- *Technical specifications are subject to change without notice due to improvement of SVEN production.*

Technical support is on www.sven.fi

External HDD Enclosure

SVEN[®]
YOU WANT – WE CAN



Модель: 3E-205E

Импортер в России: ООО «СКАНДИТРЕЛ»,
111024, РФ, г. Москва, ул. Авиамоторная, д. 65,
стр. 1. Уполномоченная организация в России:
ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха
Энгельса, д. 75, стр. 5. Условия гарантийного
обслуживания смотрите в гарантийном талоне
или на сайте www.sven.fi

Гарантийный срок: 12 мес. Срок службы: 2 года.
Производитель: «СВЕН ПТЕ. Лимитед»,
176 Джу Чиат Роуд, № 02-02, Сингапур, 427447.
Произведено под контролем «Свен Скандинавия
Лимитед», 48310, Финляндия, Котка,
Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road,
№ 02-02, Singapore, 427447. Produced under the
control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie,
Kotka, Finland, 48310. Made in China.

© Registered Trademark of Oy SVEN
Scandinavia Ltd. Finland.

SE-205E