

SVEN[®]
YOU WANT – WE CAN

Standard Wireless Keyboard

USER'S MANUAL



**ELEGANCE 5800
WIRELESS**

www.sven.fi

Congratulations on the purchase of Sven keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in safe place for future reference.

COPYRIGHT

© 2016. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

PACKAGE CONTENTS

- Wireless keyboard – 1 pc
- 2.4 GHz USB nano receiver – 1 pc
- AAA battery – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc


SPECIAL FEATURES

- Slim design
- Standard keyboard layout
- Energy-saving wireless technology
- Browser quick access key
- USB Interface
- Low-profile keys with smooth stroke

SYSTEM REQUIREMENTS

- OC Windows XP/Vista/7/8.
- Free USB port.

DESCRIPTION OF QUICK ACCESS KEY AND INDICATOR FUNCTIONS

 – Browser quick access key

 – Low battery power indicator

INSTALLATION

- Open the cover of the battery compartment at the bottom of the keyboard, insert one AAA battery matching the polarity and close the cover of the battery compartment (see Fig. 1).



Please match the polarity when installing the battery. Incorrect polarity can cause malfunction of the device, which gives no claims for warranty servicing.




Fig. 1

CONNECTION

- Connect the 2.4 GHz USB nano receiver to a free USB port of your PC.
- Wireless connection of the keyboard with nanoreceiver is automatic.
- After completion of work the nanoreceiver can be left in USB port.
- If wireless connection with the nanoreceiver is missed, it is necessary to establish a connection once again by pressing "ESC" and "+=" keys simultaneously.

Notes:

- **If battery runs down, there are "lapses" in operation of the keyboard and the low battery power indicator lights up. In such a case replace the battery with a new one.**
- **If there is a long pause in operation of the keyboard, it enters the Sleep mode. To enter the operation mode just press any button.**

TROUBLESHOOTING

Problem	Solution
The keyboard is not working.	<ol style="list-style-type: none"> 1. Check whether the battery has been installed correctly. If necessary, replace the battery with a new one matching the polarity. 2. Pull out the USB receiver and insert it back, make sure that it is not damaged. 3. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	105
Additional keys	1
Keyboard layout	Rus/Ukr/Eng
OS compatibility	Windows XP/Vista/7/8
Interface	USB
Extrapolated mean life	more than 20,000,000 strokes
Dimensions (W × H × L), mm	426 × 25 × 125
Weight, g	362

Notes:

- **Technical specifications given in this table are supplemental information and can not give occasion to claims.**
- **Technical specifications are subject to change without notice due to improvement of SVEN production.**

Standard Wireless Keyboard

SVEN®
YOU WANT – WE CAN



Model: **Elegance 5800 Wireless**

Импортер в России: ООО «РЕГАРД», 109052, РФ, г. Москва, ул. Нижегородская, д. 86, корп. Б. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мес. Срок службы: 2 года. Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котolahdentie, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

© **Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.**

**ELEGANCE 5800
WIRELESS**