

SVEN®
YOU WANT – WE CAN

Keyboard + Mouse
Wireless Combo Set

USER'S MANUAL



**ELEGANCE 5900
WIRELESS**

www.sven.fi

Congratulations on your purchase of the Sven Keyboard + Mouse Wireless Combo Set!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT

© 2014. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on «as is» terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

UNPACKING

Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.

CONTENTS

1. SPECIAL FEATURES	2
2. PACKAGE CONTENTS	2
3. SYSTEM REQUIREMENTS	2
4. MOUSE DESCRIPTION	2
5. INSTALLATION	2
6. CONNECTION	3
7. DESCRIPTION OF SHORTCUT BUTTONS FUNCTIONS	4
8. TROUBLESHOOTING	4
9. TECHNICAL SPECIFICATIONS	4

1. SPECIAL FEATURES

- Ergonomic design of the keyboard and mouse
- Energy-saving wireless technology
- 2.4 GHz USB nano receiver
- Coverage range up to 10 m
- Automatic detection, no need to match the receiver with the pointing device
- 14 shortcut buttons for Internet and Multimedia
- Compatible with Windows XP/Vista/7/8
- USB Interface
- Low operation noise
- Wireless mouse with 5 buttons and scroll wheel
- Forward/back navigation buttons
- 800/1600 dpi mouse resolution

2. PACKAGE CONTENTS

- Wireless keyboard — 1 pc
- Wireless mouse — 1 pc
- 2.4 GHz USB nano receiver — 1 pc
- AAA batteries — 3 pcs
- User's manual — 1 pc
- Warranty card — 1 pc

3. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8.
- Free USB port.

4. MOUSE DESCRIPTION

- ① Scroll wheel
- ② Additional navigation buttons
- ③ Dpi resolution switch
- ④ ON/OFF power switch
- ⑤ Optical sensor
- ⑥ Battery compartment
- ⑦ Nano receiver
- ⑧ USB connector

5. INSTALLATION

- Open the cover of the mouse battery compartment ⑥, insert 2 AAA batteries into the battery compartment matching the polarity, and close the cover of the battery compartment (Fig. 4).
- Open the cover of the battery compartment at the bottom of the keyboard, insert AAA battery matching the polarity, and close the cover of the battery compartment (see Fig. 4).




Fig. 1. Top view




Fig. 2. Bottom view




Fig. 3. Nano receiver

ELEGANCE 5900 WIRELESS




Fig. 4

6. CONNECTION

- Connect the included nano receiver ⑦ to a free PC USB port (Fig. 5).
- Turn on the mouse with the on/off switch ④ (the ON position). To activate the mouse, press any button of the mouse or turn the scroll wheel. If the mouse is connected correctly, it will turn on automatically.
- After finishing work turn off the mouse with the power switch ④ (the OFF position). After this, you can pull out the receiver ⑦ from the PC USB port and insert it into the mouse (Fig. 6). When using the receiver again, pull it out from the mouse (Fig. 7) and connect it to the PC USB port again.
- If the mouse or keyboard don't work, connect them to the nano receiver again. To reconnect the mouse to the nano receiver, press its right button and the scroll wheel at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port. To reconnect the keyboard to the nano receiver, press its «ESC» и «K» buttons at the same time and, while holding them, pull out and insert the 2.4 GHz nano receiver back into the USB port.

Notes:

- **Do not place the receiver into a confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.**
- **If batteries run down, there are «lapses» in operation of the mouse or keyboard. In such a case replace the batteries with new ones (Fig. 4).**
- **If there is a long pause in operation of the mouse or keyboard, they enter the Sleep mode. To enter the working mode just press any button.**




Fig. 5. Receiver connection




Fig. 6




Fig. 7

7. DESCRIPTION OF SHORTCUT BUTTONS FUNCTIONS

Open home web page	Go to previous track	Mute on/off
Start default E-mail program	Go to next track	Open My Compute
Open My Favorites	Play/Pause	Start media player
Go to search page	Volume down	Start/Close Calculator
Turn off media player	Volume up	

8. TROUBLESHOOTING

Problem	Solution
The keyboard and mouse are not working.	<ol style="list-style-type: none"> 1. Check whether the batteries have been installed correctly. If necessary, replace the batteries with new ones matching the polarity. 2. Pull out the USB receiver and insert it back, make sure that it is not damaged. 3. Reprogram the USB nano receiver using the software you can download at www.sven.fi. 4. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

9. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	104
Q-ty of shortcut buttons	14
Q-ty of mouse buttons	5 + 1 (scroll wheel)
Keyboard layout	Rus/Ukr/Eng
OS required	Windows XP/Vista/7/8
Interface	USB
Error-free running time	more than 20,000,000 strokes
Coverage range, m	up to 10
Mouse resolution, dpi	800/1600
Frequency, GHz	2.4
Size of keyboard (W × H × L), mm	458 × 24 × 159
Size of mouse (W × H × L), mm	67 × 41 × 106
Weight of keyboard / mouse, g	444/82

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications are subject to change without notice due to the improvement of SVEN production.**

Keyboard + Mouse Wireless Combo Set

SVEN®
YOU WANT – WE CAN



Модель: **Elegance 5900 Wireless**

Импортер в России: ООО «СКАНДИТРЕЛ», 111024, РФ, г. Москва, ул. Авиамоторная, д. 65, стр. 1.

Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5. Условия гарантийного обслуживания смотрите

в гарантийном талоне или на сайте www.sven.fi

Гарантийный срок: 12 мес. Срок службы: 2 года.

Производитель: «СВЕН ПТЕ. Лимитед»,

176 Джу Чиат Роуд, № 02-02, Сингапур, 427447.

Произведено под контролем «Свен Скандинавия

Лимитед», 48310, Финляндия, Котка,

Котлахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD., 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

© **Registered Trademark of Oy SVEN
Scandinavia Ltd. Finland.**

**ELEGANCE 5900
WIRELESS**