

# Keyboard

# **USER'S MANUAL**





## Congratulations on the purchase of Sven keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in safe place for future reference.

#### COPYRIGHT

© 2019. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

#### **TRADEMARKS**

All trademarks are the property of their legal holders.

#### UNPACKING

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

#### **APPLICATION**

KB-E5500 keyboard is an input device. It is designed to enter information into the computer, as well as controll the operation of the computer.

#### PACKAGE CONTENTS

- Keyboard 1 pc
- User's Manual 1 pc

### **SPECIAL FEATURES**

- · Slim design
- 12 multimedia functions Fn
- · Ergonomic wrist rest
- · Low-profile keys with smooth stroke

#### SYSTEM REQUIREMENTS

- OC Windows.
- Free USB port.

### INSTALLATION

- Connect the keyboard to an available USB port of your PC.
- Installation of keyboard is automatic after its connection to USB port of PC.

#### **DESCRIPTION OF QUICK ACCESS KEY FUNCTION**

Fn + F1 - start Media player

Fn + F2 – volume down

Fn + F3 - volume up

Fn + F4 - mute on/of

Fn + F5 - previous track

Fn + F6 - next track

Fn + F7 - play/pause

## **User's Manual**

# KB-E5500

Fn + F8 - stop playing music

Fn + F9 - open home web page

Fn + F10 - start E-mail program

Fn + F11 - open My Computer

Fn + F12 - open "favorites" in the browser

Note. Press the shortcut keys while holding the Fn key.

### **TROUBLESHOOTING**

Problem	Solution
The keyboard is not working.	Disconnect keyboard from PC and check connector pins for possible damage. If there is no external damage found and connector pins are OK, connect keyboard to PC again. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

#### TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	104
Additional keys	12 (Fn)
Keyboard layout	Rus/Ukr/Eng
OS compatibility	Windows
Interface	USB
Extrapolated mean life	more than 20,000,000 strokes
Dimensions (W × H × L), mm	450 × 26 × 185
Weight, g	628

#### Notes:

- Technical specifications given in this table are supplemental information and can not give occasion to claims.
- Technical specifications are subject to change without notice due to improvement of SVEN production.

Technical support: www.sven.fi.

# Keyboard





Model: KB-E5500

Импортер в России: ООО «РЕГАРД», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания см. в гарантийном талоне или на сайте **www.sven.fi.** Гарантийный срок: 12 мес. Срок службы: 2 года. Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.

EH[ C € ⊕

KB-E5500