

Wired Keyboard

USER'S MANUAL



KB-E5700H

www.sven.fi



Congratulations on the purchase of Sven keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in safe place for future reference.

COPYRIGHT

© SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damages which have arisen from the information contained in the given Manual.

UNPACKING

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

KB-E5700H keyboard is an input device. It is designed to enter information into the computer, as well as controll the operation of the computer.

PACKAGE CONTENTS

- Keyboard 1 pc
- User's Manual 1 pc
- Warranty card 1 pc

SPECIAL FEATURES

- · 2 USB-ports
- 12 media (FN) keys
- Waterproof construction
- Slim design

SYSTEM REQUIREMENTS

- OC Windows.
- · Free USB port.

INSTALLATION

- Connect the keyboard to an available USB port of your PC.
- Installation of keyboard is automatic after its connection to USB port of PC.

KB-E5700H

DESCRIPTION OF QUICK ACCESS KEYS FUNCTION

Fn + F1 🮜 – Start media player

Fn + F2 ◀)» – Volume down

Fn + F4 @ - Mute/turn on sound volume

Fn + F6 → Go to next media track

Fn + F7 ►/II - Play/Pause

Fn + F8 _ - Turn off media player

Fn + F9
— Open home web page

Fn + F10 \square - Start default e-mail program

Fn + F12 - Open bookmarks

Note. Press the shortcut keys while holding the Fn key.

TROUBLESHOOTING

Problem	Solution
Keyboard is not working.	Disconnect keyboard from PC and check connector pins for possible damage. If there is no external damage found and connector pins are OK, connect keyboard to PC again. We recommend to address the nearest authorized service center.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys, pcs	104
Q-ty of keyboard shortcut keys, pcs	12 (Fn)
Keyboard layout	Eng/Rus/Ukr
OS compatibility	Windows
Interface	USB
Length of cable, m	1,5
Dimensions, mm	455 × 145 × 28 (38)
Weight клавиатуры, g	423

Notes:

- Technical specifications given in this table are supplemental information and can not give occasion to claims.
- Technical specifications are subject to change without notice due to improvement of SVEN production.

Wired Keyboard





Model: KB-E5700H

Импортер в России: ООО «Регард», 105082, г. Москва, ул. Фридриха Энгельса, д.75, стр. 5. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мес. Срок службы: 5 лет. Производитель: «СВЕН ПТЕ. Лимитед». 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.



KB-E5700H