

SVEN[®]

Gaming Keyboard

USER MANUAL



KB-G8600

www.sven.fi

Congratulations on the purchase of Sven keyboard!

Please read this User's Manual before using the unit and retain this User's Manual in safe place for future reference.

COPYRIGHT

© SVEN PTE. LTD. Version 1.0 (V 1.0). This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damages which have arisen from the information contained in the given Manual.

UNPACKING

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

KB-G8600 keyboard is an input device. It is designed to enter information into the computer, as well as control the operation of the computer.

PACKAGE CONTENTS

- Keyboard – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES

- Programmable keys.
- WIN key lock.
- Keyboard brightness backlighting adjustment.
- Durable braided cable.

SYSTEM REQUIREMENTS

- OC Windows.
- Free USB port.

INSTALLATION

- Connect the keyboard to an available USB port of your PC.
- Installation of keyboard is automatic after its connection to USB port of PC.

DESCRIPTION OF QUICK ACCESS KEYS FUNCTION

Fn + F1	Start media player	Fn + F10	Open homepage
Fn + F2	Volume down	Fn + F11	Lock keyboard
Fn + F3	Volume up	Fn + F12	Start calculator
Fn + F4	Mute/Unmute	Fn + ↑	Increase backlight brightness level
Fn + F5	Stop playing	Fn + ↓	Decrease backlight brightness level
Fn + F6	Play previous track	Fn + ←	Increase backlight flashing speed
Fn + F7	Play/Pause	Fn + →	Decrease backlight flashing speed
Fn + F8	Play next track	Fn + W	Switch WASD keys to arrows and back
Fn + F9	Start e-mail app	Fn + WIN	WIN key lock

Note. Press the shortcut keys while holding the Fn key.

The backlighting modes can be changed by the following shortcut keys:

FN + Delete, FN + Insert, FN + Home, FN + End, FN + PgUp, FN + PgDn.

Work with macro commands

- Press the keys «FN + REC» to start macro recording. The LEDs will start flashing.
- Enter the keys sequence, which should be saved as macro.
- Press one of the keys G1–G4, which will be used for macro.
- To reset all macros press «FN + CK» and hold during 3-4 seconds. The keyboard will be returned to the default settings.

TROUBLESHOOTING

Problem	Solution
Keyboard is not working.	1. Disconnect keyboard from PC and check connector pins for possible damage. If there is no external damage found and connector pins are OK, connect keyboard to PC again. 2. We recommend to address the nearest authorized service center.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys, pcs	110
Q-ty of media keys, pcs	12 (Fn)
Keyboard layout	Eng/Rus/Ukr
OS compatibility	Windows
Interface	USB
Dimensions, mm	475 × 215 × 36 (46)
Weight клавиатуры, g	849

Notes. Technical specifications given in this table are supplemental information and can not give occasion to claims. Technical specifications are subject to change without notice due to improvement of SVEN production.

Gaming Keyboard

SVEN®

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447.
Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

© Registered Trademark
of Oy SVEN
Scandinavia Ltd. Finland.



0B0604

KB-G8600