SVEN®

YOU WANT – WE CAN

Wired Optical Mouse

USER'S MANUAL

RX–150

www.sven.fi

User's Manual

RX−150

Congratulations on purchasing the SVEN mouse!

Please read this User's Manual before using the unit and retain this User's Manual in a safe place for future reference.

COPYRIGHT
© 2016. SVEN PTE. LTD. Version 1.0 (V 1.0).
This User's Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS
All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION
Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

CONTENTS

Technical support: www.sven.fi

SVEN®

YOU WANT – WE CAN

Wired Optical Mouse

1. SAFETY PRECAUTIONS
• Protect your mouse from high humidity, dust or high temperatures.
• Do not use gasoline, spirit or other dissolvents for cleaning. This may cause damage to the surface. Clean the device with soft cloth.
• Do not attempt to disassemble or repair your device.
• Protect the device against powerful shocks and falls – they may damage the internal electronics.

2. PACKAGE CONTENTS
• Wired Optical Mouse — 1 pc
• USB-PS/2 adapter — 1 pc
• User's manual — 1 pc
• Warranty card — 1 pc

3. SPECIAL FEATURES
• High-precision optical technology
• Operates practically on any surface
• Stylish ergonomic design
• USB interface (USB-PS/2 adapter)
• 800 dpi resolution
• Drivers installation not required for Windows XP/Vista/7/8/10

4. SYSTEM REQUIREMENTS
• Windows XP/Vista/7/8/10
• Free USB port

5. CONNECTION AND INSTALLATION
• Connect the mouse to an available USB or PS/2 port of your PC.
• Turn on your PC. Installation of the mouse is automatic.
• In addition to the left and right buttons, the mouse also has a scroll wheel combined with the third button. The scroll wheel enables you to look through and turn pages of documents in Windows OS.

6. TROUBLESHOOTING

Problem	Solution
The mouse is not working.	1. Disconnect the mouse from your PC and check the connector pins for possible damage. If there is no external damage found and the connector pins are OK, connect the mouse to your PC again. 2. Address your nearest authorized service center.

If none of the above mentioned solutions removes the problem, please consult a nearest authorized service center. Never try to repair the device on your own.

7. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
OS required	Windows XP/Vista/7/8/10
Type of mouse	optical
Resolution, dpi	800
Q-ty of buttons	2 + 1 (scroll wheel)
Interface	USB (USB-PS/2 adapter)
Standards compliance	FCC, CE

Notes:
• Technical specifications given in this table are supplemental information and cannot give occasion to claims.
• Technical specifications are subject to change without notice due to the improvement of SVEN production.

Wired Optical Mouse

SVEN ®

YOU WANT – WE CAN

RX-150