

SVEN[®]

Portable Speaker System
with Bluetooth and FM-radio

USER'S MANUAL



PS-175
PS-185
PS-190

www.sven.fi

Congratulations on your purchase of the SVEN speaker system!

COPYRIGHT

© 2017. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

BUYER RECOMMENDATIONS

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

APPLICATION

SVEN PS-175/PS-185/ PS-190 portable multimedia speaker system with Bluetooth and FM-radio is designed for operation with PC, notebooks and other mobile devices by means of data transfer via Bluetooth protocol. They can be also used in internet telephony, during video conferences, in multimedia applications, in interactive games, for speech recognition and foreign language teaching. There is a built in FM-tuner, and player with USB flash and with micro SD memory card.

PACKAGE CONTENTS

- Speaker system – 1 pc
- 3,5 mm mini-jack to 3,5 mm mini-jack signal cable – 1 pc
- USB to micro USB power cable – 1 pc
- User's Manual – 1 pc
- Warranty card – 1 pc

SPECIAL FEATURES

- Wireless signal transmission via Bluetooth
- Built-in audio files player from USB-flash and microSD card storage devices
- Built-in clock and alarm function
- Build-in FM radio
- LED display
- Carrying handle (only model SVEN PS-185)
- Wired connection

Speaker system description

① Play/Pause button (in Bluetooth/Player mode);
Start/Stop auto scan (long pressing in Radio mode);
MUTE mode (short pressing in Radio mode/LINE);
Receive / end a call button;

Clock and alarm clock button (long pressing)

② MODE: Switching modes button (short pressing):
Clock / Date / Alarm clock / Bluetooth / Player / Radio/LINE/Sleep*;
Turning off the display* (long pressing)

③ Previous track (in Bluetooth/player mode);

Previous track (in Radio mode);

Setting the clock / alarm;

Changing the format of the clock (12/24)

* - only model SVEN PS-190




Fig. 1. Speaker system description

- ④ Next track (in Bluetooth/Player mode);
Go to the next station (in FM radio mode)
- Setting the clock / alarm;
- Changing the format of the clock (12/24)
- ⑤ Vol-: Volume decrease
- ⑥ Vol+: Volume increase
- ⑦ AUX: 3.5 mm mini-jack for audio signal
connecting (phone, MP3 player, etc.)
- ⑧ Micro SD: micro SD card slot
- ⑨ USB HOST: USB flash connector
- ⑩ USB DC: Micro USB jack for connecting speakers to
the charger, the USB port of laptop / PC
- ⑪ Indicator
- ⑫ ON / OFF button
- ⑬ Display (on the front panel)
- ⑭ Microphone (behind the display)



Fig. 2. Front view

CONNECTION AND OPERATION

Attention! *The built-in battery must be charged completely prior to the application.*

Speaker system battery charging

- Connect speaker system to a USB port of PC or USB charger using micro USB to USB cable (included). During battery charging the indicator ⑪ is red.
- The battery is used in the speaker system as an integral part of the device, therefore do not try to extract or replace it, because this can result in the warranty cancellation or the device damage.

OPERATION MODES

Bluetooth mode

- Wireless data transfer via the Bluetooth protocol enables to connect speaker system to compatible devices. Maximum radius of action of data transfer is 10 m. Such obstacles as walls or other electronic devices can interfere with the signal transfer.




Fig. 3. Connection diagram

- Turn on the speaker system Bluetooth mode – press button ② several times until the display will not show "BLUE".
- It is necessary to select the search mode of devices with Bluetooth on a signal source (telephone, notebook, smartphone, etc.). «SVEN PS-175/PS-185/PS-190» message will be displayed on the screen which is to be connected to*.
- When connection is successful, there will be a short beep and the indication of the search mode on speaker system is over**.

* You might have to enter "0000" code to connect some models of devices via Bluetooth.

** If the item has been already registered in the device list of a source, then the second search mode activation is not obligatory. Choose the item name "SVEN PS-175/PS-185/PS-190" and the "connect" command on the source.

Radio mode

To improve radio reception, connect the cable USB-micro USB cable (included) to the input ⑩.

- Turn on the speaker system – press button ② several times until, the radio mode will not turn on. Long press the button ① activates auto search mode. After scanning completion, the first scanned radio station will start to operate automatically. With buttons ③ and ④ select a desired radio station.

MP3 player mode

Attention! The file system of a micro SD or USB flash carrier is FAT32. Maximum volume is 32 GB. It is not recommended to use the micro SD Ultra Speed.

• Insert the USB flash or micro SD carrier into appropriate slot. If the speaker system is in turned on position, the playback will start automatically. Playback/Pause modes are switched over with the help of the button ①. Tracks can be controlled by buttons ③ (previous track) and ④ (next track).

Clock mode

• Turn the speakers on in clock mode – press the button ② repeatedly until the clock mode turns on.

• Enter the setting mode by long pressing the button ①. Set the desired date, hour, minute using the buttons ③ and ④. Between the date / hour / minute setting and exit from the setting mode, press the button ①.

Alarm clock mode

• Turn on the speakers in the alarm mode – press the button ② repeatedly until the alarm mode turns on.

• Enter the time setting mode by long pressing the button ①.

• Set the desired hours and minutes using the ③ and ④ buttons.

Between the hour / minute setting and exit from the setting mode, press the button ①.

Note: It is possible to set your alarm melody:

- 1) Create the "ALARM" folder on a USB-flash or microSD memory card;**
- 2) Record a music file with the extension .mp3 in the folder ALARM;**
- 3) Insert a USB-flash or microSD card with the recorded file in the AS;**
- 4) At the setted time, the alarm will play the recorded file.**

SLEEP mode (only for model SVEN PS-190)

• SLEEP mode allows you to transfer the product to ST-BY mode after the user-selected time has elapsed. To switch to SLEEP mode, press the button ② repeatedly until SOFF appears on the display.

• Set the OFF time (OFF / 15/30/60/120 min) – press the button ① the required number of times. To exit SLEEP mode, press the button ② again.

The use in the wired mode (Line)

- Speaker system can be used as an external device for amplifying any audio source with a 3.5 mm output mini-jack. To do this, connect a cable mini USB, plug 3.5 mini-jack to the audio output AUX ⑦.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, Hz	speaker: 100 – 22,000 microphone: 50 – 16,000
Output power (RMS), W:	10 (2 × 5)
Membrane, mm	∅ 53
Bluetooth supported profiles	HSP, HFP, A2DP, AVRCP
Battery operation time, h	till 10
Battery capacity, mA * h	2000
Power supply, V	USB/DC5V
Weight, g	0.63 (PS-175), 0.9 (PS-185), 0.8 (PS-190)
Dimensions, mm	218 × 70 × 70 (PS-175), 240 × 137 × 70 (PS-185), 229 × 70 × 95 (PS-190)

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications are subject to change without notice due to improvement of SVEN production.**

Technical support: www.sven.fi.

Portable Speaker System with Bluetooth and FM-radio

SVEN®



Model: PS-175, PS-185, PS-190

Импортер в России: ООО «РЕГАРД», 109052,
РФ, г. Москва, ул. Нижегородская, д. 86, корп. Б.
Уполномоченная организация в России: ООО «РТ-Ф»,
105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.

Условия гарантийного обслуживания смотрите
в гарантийном талоне или на сайте www.sven.fi.

Гарантийный срок: 12 мес.

Срок службы: 2 года.

Производитель: «СВЕН ПТЕ. Лимитед»,

176 Джу Чиаг Роуд, № 02-02, Сингапур, 427447.

Произведено под контролем «Свен Скандинавия
Лимитед», 48310, Финляндия, Котка,
Котлахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road,
№ 02-02, Singapore, 427447. Produced under the
control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie,
Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN
Scandinavia Ltd. Finland.



PS-175 PS-185 PS-190