

USER MANUAL



PS-275

www.sven.fi



Congratulations on your purchase of the SVEN speaker system!

COPYRIGHT

© SVEN PTE, LTD, Version 1.0 (01.08,2021).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

BUYER RECOMMENDATIONS

- Unpack the device carefully. Make sure there are no accessories left in the box. Check
 up the device for damage; if the product was damaged during transportation, address
 the firm which carried out the delivery; if the product functions incorrectly, address
 the dealer at once.
 Check up the package contents and availability of the warranty card. Make sure
- the warranty card has a shop stamp, a legible signature or the seller's stamp and purchase date, and the goods number corresponds to that in the warranty card. Remober: in case of warranty card loss or discrepancy of numbers you forfeit the right for warranty repairs.
- Before installing and using the speaker system, read this Manual carefully and keep it for future reference.
- · Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.
- The date of manufacture of the product is indicated on the box.

APPLICATION

SVEN PS-275 portable multimedia speaker system with Bluetooth and FM-radio is designed for operation with PC, notebooks and other mobile devices by means of data transfer via Bluetooth protocol. It can be also used in Internet telephony, during video conferences, in multimedia applications, in interactive games, for speech recognition and foreign language teaching. FM-tuner and the player with USB-flash and micro SD-cards are included.

PACKAGE CONTENTS


- Speaker system 1 pc
- 3.5 mm mini-jack to 3.5 mm mini-jack signal cable 1 pc
- USB to Type-C power cable 1 pc
- User Manual 1 pc
- Warranty card 1 pc

SPECIAL FEATURES

- · Bluetooth wireless signal transmission
- Protection against the water (IPx5)
- · Wireless connection of two speakers to one source
- Built-in audio files player from USB-flash and microSD card storage devices
- · Built-in FM tuner
- Wired connection
- Rotary volume level control

Speaker system description

- Rotary volume level control
 A: Next track (in Player and Bluetooth mode);
- Next station (in Radio mode)
- 3 v: Previous track (in Player and Bluetooth mode);
- Previous station (in Radio mode)
- Change backlight mode (short pressing);
- Backlight on/off (long pressing);
- Disconnect from device (double click in Bluetooth mode)
- ⑤ O: POWER button (long pressing):
- Play/Pause button (short pressing in Player and Bluetooth mode):
- Mute (short pressing in Radio mode or LINE):
- Start/Stop auto scan (double click) Соппесting an additional speaker (short pressing в режиме Bluetooth)
- Switch mode button: Bluetooth/FM/Player/LINE (long pressing)
- 3.5 mm mini-jack for audio signal connecting (phone, MP3 player, etc.)
- USB-flash card slot
- USB Type C jack for charger connecting speaker system to laptop/PC USB port
- @ Micro SD card slot
- (f) Indicator





CONNECTION AND OPERATION

Attention! The built-in battery must be charged completely prior to the application. Speaker system battery charging

- Connect speaker system to a USB port of PC or USB charger using Type-C to USB cable (included). When charging, the indicator ① lights up in red. Indicator ② goes out if the battery is charged.
- The battery is used in the speaker system as an integral part of the device, therefore do not try to extract or replace it, because this can result in the warranty cancellation or the device damage.

OPERATION MODES

Bluetooth mode

- Wireless data transfer via the Bluetooth protocol enables to connect speaker system to compatible devises. Maximum radius of action of data transfer is 10 m. Such obstacles as walls or other electronic devices can interfere with the signal transfer.
- . Turn on the speakers in Bluetooth mode.
- It is necessary to select the search mode of devices with Bluetooth on a signal source (telephone, notebook, smartphone, etc.). «SVEN PS-275» massage will be displayed on the screen which is to be connected to*.
- When connection is successful, there will be a short beep**.

Radio mode

To improve radio reception, connect USB-Type-C cable (included) to the input ①.

 Turn on the speaker system – press button @ several times until, the radio mode will turn on. Double press button @ activates auto search mode. After scanning completion, the first scanned radio station will start to operate automatically. With buttons @ and @ select a desired radio station.

MP3 player mode

Attention! The file system of a micro SD or USB flash carrier is FAT32. Maximum volume is 32 GB. It is not recommended to use the micro SD Ultra Speed.

 Insert the USB flash or micro SD carrier into appropriate slot. If the speaker system is in turned on position, the playback will start automatically, Playback/Pause modes re switched over with the help of the button ③, Tracks can be controlled by buttons ③ (previous track) and ⑥ (next track).

Connecting an additional speaker

- For model «SVEN PS-275» you can connect an additional speaker (Bluetooth mode only):

 Connect one speaker to a signal source via Bluetooth.
- Connect one speaker to a signal source via Bluetooth.
 Briefly press button (a) on the connected speaker, to activate the search mode, the
- second speaker must be in the search for BT.

 The speakers will connect with each other.

Note. At the subsequent inclusion of both speakers, they will be connected automatically.

You might have to enter «0000» code to connect some models of devices via Bluetooth. *If the item has been aiready registered in the device list of a source via Bluetooth. search mode activation is not obligatory. Choose the item name «SVEN PS-275» and the «connect» command on the source.




Fig. 2. Connection diagram

The use in the wired mode (AUX)

 Speaker system can be used as an external device for amplifying any audio source with a 3.5 mm output mini-jack. To do this, connect a cable 3.5 mini-jack – 3.5 mini-jack to the audio input AUX ①.

TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Frequency range, Hz	120-20000
Output power (RMS), W	12 (2 × 6)
Membrane, mm	Ø 52
Rated current consumption, A	0.14
Battery capacity, mA*h	2400
Power supply	USB / === 5 B
Weight, g	800
Dimensions, mm	89,5×215×91

Notes:

- Technical specifications given in this table are supplemental information and cannot give occasion to claims.
- Technical specifications and package contents are subject to change without notice due to the improvement of SVEN production.

SVEN®

Model: PS-275

Importer: Tiralana OY, Office 102, Kotolahdentie 15, 48310 Kotka, Finland.

Импоргер в России: ООО «Регард», 10582, г. Москва, ил. Фидириа Энгельса, д. 75, стр. 5. Уполномоченная организация в рессии: ООО «РТ-Ф», 105082, г. Москва, ул. Фридрика Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мес. Соок службы, ≥ гова.

Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, No 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15. Kotolahdentie. Kotka. Finland.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.

48310. Made in China.



PS-275