

SVEN[®]

Wireless Gamepad

OPERATION MANUAL



GC-3050

www.sven.fi

Congratulations on the purchase of Sven gamepad!

Please read this Operation Manual before using the unit and retain this Operation Manual in safe place for future reference.

COPYRIGHT

SVEN PTE. LTD. Version 1.0 (20.09.2021).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on «as is» terms. The author and the publisher do not bear any liability to a person or an organization for loss or damages which have arisen from the information, contained in the given Manual.

CONTENTS

1. BUYER RECOMMENDATIONS	2
2. DESCRIPTION	3
3. PACKAGE CONTENTS	3
4. SAFETY PRECAUTIONS.....	3
5. SPECIAL FEATURES.....	3
6. SYSTEM REQUIREMENTS	3
7. DESCRIPTION OF THE CONSTRUCTION	4
8. CONNECTION AND INSTALLATION	5
9. TROUBLESHOOTING.....	7

1. BUYER RECOMMENDATIONS

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Check up the package contents and availability of the warranty card. Make sure the warranty card has a shop stamp, a legible signature or the seller's stamp and purchase date, and the number of the wall mount corresponds to that in the warranty card. Remember: in case of warranty card loss or discrepancy of numbers you forfeit the right for warranty repairs.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.
- The date of manufacture of the product is indicated on the box.

Technical support is on www.sven.fi.

2. DESCRIPTION

GC-3050 wireless gamepad can be used in different games such as simulators, arcades, shooter games etc. Vibration feedback imparts a feeling of realistic experience during games. Rubber coating and ergonomic construction of GC-3050 enhance accuracy of its operation during games.

3. PACKAGE CONTENTS

- Gamepad — 1 pc
- 2.4GHz USB Nano-Receiver — 1 pc
- Power cable USB to micro USB — 1 pc
- Operation Manual — 1 pc
- Warranty card — 1 pc

4. SAFETY PRECAUTIONS

- Do not disassemble or repair the device on your own. Maintenance and repairs should be carried out by qualified service centre staff only.
- Protect the device from direct impact of high humidity, dust, strong magnetic fields, vibrations, high temperatures, toxic liquids and gases.
- Instructions for device maintenance: for cleaning the case of the device please use clean soft cloth. Do not use such solvents as gasoline or spirit for cleaning, since these solvents can damage the surface of the device.
- Do not drop the device to avoid damaging it.

5. SPECIAL FEATURES

- Ergonomic design of the gamepad
- X-Input and Direct-Input modes support
- Supports: Windows 7/8/10, PS3, Android*
- USB Interface
- Turbo function for continuous firing
- Built-in battery
- 4 axes, D-Pad, 2 mini joysticks and 13 buttons
- Soft-touch coverage for confident control while playing
- Digital and analog modes available

6. SYSTEM REQUIREMENTS

- USB port available
- Windows 7/8/10, PS3, Android* Operational System

* There may be incompatibility with individual versions of Android and models of Android-devices.

7. DESCRIPTION OF CONSTRUCTION

- ① D-Pad
- ② Button SELECT
- ③ Button TURBO
- ④ Button CLEAR
- ⑤ Button START
- ⑥ Buttons 1-4
- ⑦ Left joystick
- ⑧ Button HOME
- ⑨ Operation mode indicators
- ⑩ Right joystick
- ⑪ Button R1
- ⑫ Button L1
- ⑬ Button R2
- ⑭ Connector for charging
- ⑮ Button L2
- ⑯ Button RESET
- ⑰ USB nano-receiver




Fig. 1. Top view




Fig. 3. Bottom view




Fig. 2. Front view



Fig. 4. USB nano-receiver

8. CONNECTION AND INSTALLATION

- Connect the USB receive ⑩ to an available USB port on the computer.

- Download the software from the official site from the product page and run the program «SVEN Gamepad.exe».

- In order to test and configure the gamepad, choose «Control Panel» «Devices and Printers», in the Windows control panel (in the «XInput» mode, the gamepad is displayed as «Xbox 360 Controller for Windows», in the «DirectInput» - «PC / PS3 / PC360 / ANDROID»), then right-click on the device icon and select. Gaming device parameters (administrator rights may be required) (Fig.5,6). The «Game devices» window will appear. In XInput mode, the gamepad is displayed as «Controller (XBOX 360 For Windows)» (Fig. 7), in the «DirectInput» mode - «USB Vibration Joystick (BM)» (Fig.8). To switch between the «DirectInput» and «XInput» modes, you must press the HOME button for 6 seconds.

- To check and configure in «XInput» mode, select «Properties» in the «Game devices» window, the «Properties: Controller (XBOX 36 ...» window will pop-up (Fig.9). In the «Verification» tab, you can check the execution of commands when you press the buttons and rotate the joystick. To calibrate the joystick, select the «Settings» tab, click «Calibrate» and follow the instructions.

- To check and configure in DirectInput mode, select Properties in the Game Devices window, and the Properties: USB Vibration Joystick (BM) window pops up. In the «Test» tab, you can check the execution of commands when you press the buttons and rotate the joysticks, and also check whether the joystick is connected to the PC in the «Connected State» line (Fig.10).In the «Calibration» tab, you can center the position of both joysticks (Fig. 10). To do this, you need to set them to the middle position, then click «Default» and «Set». After calibration, you must click «Accept» or «OK» on the bottom line of this window to save the changes.



Fig. 5



Fig. 6




Fig. 7




Fig. 8

- By pressing the «Both force» button, in the «Vibration Test» tab, you can check the operation of both vibrators together or separately, by pressing the «Left force» and «Right force» buttons. Also you can do it by rotating the left joystick in the analog mode of operation or by pressing the D-Pad in the digital mode of operation (Fig. 12). To stop the test, press the «Stop» button. Moving the cursor in the row «Vibration strength» we can increase or decrease the force of vibration. To save the settings, click «Apply» or «OK» button in the bottom line of this window.

- The «About» tab provides information about the version of the installed driver.

- TURBO mode.

- This mode allows you to emulate a rapid repeated press of a button while holding it. To assign the selected button to this function, it must be clamped simultaneously with the TURBO button. Press the TURBO button and the CLEAR button simultaneously to reset the function.

- There are analog and digital modes. The modes are switched by briefly pressing the HOME button. In digital mode, two axes are available, and in analog mode all 4 axes are available.

- With PS3.

- Connect the gamepad to an available USB port. The system will automatically establish a connection, and the LED corresponding to the number of the gamepad in the system will light up.

- With Android.

- To connect to devices running Android, you need a USB OTG cable (not included). After connecting the gamepad with this cable, the system will automatically establish a connection, and the first LED will light up.

- Gamepad charge.

- Connect the gamepad to the PC USB port or to the USB charger using the USB - micro USB cable (included). During charging all LEDs blink at the same time.




Fig. 9




Fig. 10




Fig. 11




Fig. 12

9. TROUBLESHOOTING

Problem	Solution
After installation of the software, the game controller does not work normally.	<p>A. Check whether the link cable of the controller is strongly connected to the PC.</p> <p>B. Open the Properties window: Controller (Controller (XBOX 36 ...) / Properties: USB Vibration Joystick (BM), and check that the gamepad is connected correctly.</p> <p>C. Press the RESET button to reset the connection.</p> <p>D. Restart your PC, if the controller still doesn't work normally.</p>
The analog axis worked automatically without the intervention of the player.	The manipulator calibration is not adjusted or confirmed after adjustment.
After starting the game, the vibro-feedback function is turned on without the player's intervention.	Enter the «Force Feedback» settings in the game, and calibrate the vibro-feedback function.
In the process of playing the vibration function is not enough.	Enter the «Force Feedback» settings in the game, and set the vibration strength.
The game controller that has been lying without work for a couple of days does not turn on.	Connect it to the power supply for 1-3 minutes. If after that it does not turn on, you need to charge it for a longer time.

If none of the above mentioned solutions removes the problem, please seek professional advice at your nearest authorized service center. Never try to repair the device on your own.

Wireless Gamepad

SVEN®

Model: GC-3050

Importer: Tiralana OY, Office 102, Kotolahdentie 15, 48310 Kotka, Finland.

Импортер в России: ООО «Регард», 105082, г. Москва, ул. Фридриха Энгельса, д.75, стр. 5. Уполномоченная организация в России: ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 56, стр. 1. Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте www.sven.fi. Гарантийный срок: 12 мес. Срок службы: 2 года. Производитель: «СВЕН ПТЕ. Лимитед», 176 Джу Чиат Роуд, № 02-02, Сингапур, 427447. Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котolahдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road, № 02-02, Singapore, 427447.
Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.



GC-3050