

SVEN®

Keyboard + Mouse Wireless
Combo Set + Mouse Pad

USER'S MANUAL



KB-C3800W

www.sven.fi



Congratulations on your purchase of the Sven Keyboard + Mouse + Mouse Pad Wireless Combo Set!

Please read this User’s Manual before using the unit and retain this User’s Manual in a safe place for future reference.

COPYRIGHT

© 2019. SVEN PTE. LTD. Version 1.0 (V 1.0).

This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information in this Manual is given on “as is” terms. The author and the publisher do not bear any liability to a person or an organization for loss or damage which has arisen from the information contained in this Manual.

UNPACKING

- Unpack the device carefully. Make sure there are no accessories left in the box. Check up the device for damage; if the product was damaged during transportation, address the firm which carried out the delivery; if the product functions incorrectly, address the dealer at once.
- Shipping and transportation equipment is permitted only in the original container.
- Does not require special conditions for realization.
- Dispose of in accordance with regulations for the disposal of household and computer equipment.

CONTENTS

1. APPLICATION	3
2. SPECIAL FEATURES	3
3. PACKAGE CONTENTS	3
4. SYSTEM REQUIREMENTS	3
5. INSTALLATION	3
6. CONNECTION	4
7. DESCRIPTION OF SHORTCUT BUTTONS FUNCTIONS	4
8. TROUBLESHOOTING	5
9. TECHNICAL SPECIFICATIONS	5

Technical support is on www.sven.fi.

1. APPLICATION

KB-C3800W keyboard and mouse are input devices. They are designed to enter information into the computer, as well as control the operation of the computer.

2. SPECIAL FEATURES

- Multimedia functions operations
- Wrist rest
- Island Key Type
- Energy efficient technology

3. PACKAGE CONTENTS

- Wireless keyboard — 1 pc
- Wireless mouse — 1 pc
- Mouse Pad — 1 pc
- 2.4 GHz USB nano receiver — 1 pc
- AAA batteries — 2 pc
- User's Manual — 1 pc
- Warranty card — 1 pc

4. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8/10.
- Free USB port.

5. INSTALLATION

- Open the cover of the mouse battery compartment, insert AA battery into the battery compartment matching the polarity, and close the cover of the battery compartment (see Fig. 1).
- Open the cover of the battery compartment at the bottom of the keyboard, insert AA battery matching the polarity, and close the cover of the battery compartment.



Please match the polarity when installing the batteries. Incorrect polarity can cause malfunction of the device, which gives no claims for warranty servicing.




Fig. 1

6. CONNECTION

- Connect the 2.4 GHz USB nano receiver to a free USB port of your PC.
- To activate the set, press any button of the mouse or turn the scroll wheel. If the connection is correct, the set will turn on automatically.
- After finishing your work, can pull out the receiver from the PC USB port and insert it into the mouse as shown in Fig. 2.

Notes:

- **Do not place the receiver into a confined metal space (table drawer, box, safe), as a metal screen does not transmit radio signals.**
- **If batteries run down, there are «lapses» in operation of the mouse or keyboard. In such a case replace the batteries with new ones.**
- **If there is a long pause in operation of the mouse or keyboard, they enter the Sleep mode. To enter the working mode just press any button.**




Fig. 2

7. DESCRIPTION OF SHORTCUT BUTTONS FUNCTIONS

Fn + F1	Start media player	Fn + F7	Play/Pause
Fn + F2	Volume down	Fn + F8	Stop
Fn + F3	Volume up	Fn + F9	Open home web page
Fn + F4	Mute / Unmute volume	Fn + F10	Start default e-mail program
Fn + F5	Go to previous track	Fn + F11	Open my computer
Fn + F6	Go to next track	Fn + F12	Open bookmarks in web browser

8. TROUBLESHOOTING

Problem	Solution
The keyboard and mouse are not working.	<ol style="list-style-type: none"> 1. Check whether the batteries have been installed correctly. If necessary, replace the batteries with new ones matching the polarity. 2. Pull out the USB receiver and insert it back, make sure that it is not damaged. 3. We recommend that you address your nearest service center.

If none of the above methods can solve the problem, please seek professional advice at your nearest service center. Never attempt to repair the product yourself.

9. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
Q-ty of keyboard keys	104
Q-ty of shortcut buttons	12
Q-ty of mouse buttons	5 + 1 (scroll wheel)
Keyboard layout	Eng/Rus/Ukr
OS compatibility	Windows XP/Vista/7/8/10
Interface	USB
Error-free running time	more than 20,000,000 strokes
Coverage range, m	up to 10
Mouse resolution, dpi	800/1200/1600
Frequency, GHz	2.4
Keyboard dimensions (W × H × L), mm	450 × 25 × 185
Mouse dimensions (W × H × L), mm	103 × 66 × 38
Weight (keyboard + mouse), g	584 and 80

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications are subject to change without notice due to the improvement of SVEN production.**

**Keyboard + Mouse Wireless
Combo Set + Mousepad Set**

SVEN®



Model: KB-C3800W

Импортер в России: ООО «РЕГАРД», 105082,
г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.
Уполномоченная организация в России:
ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха
Энгельса, д. 56, стр. 1 Условия гарантийного
обслуживания смотрите в гарантийном талоне или на
сайте www.sven.fi.

Гарантийный срок: 12 мес. Срок службы: 2 года.

Производитель: «СВЕН ПТЕ. Лимитед»,
176 Джу Чиаг Роуд, № 02-02, Сингапур, 427447.

Произведено под контролем «Свен Скандинавия
Лимитед», 48310, Финляндия, Котка,
Котлахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD, 176 Joo Chiat Road,
№ 02-02, Singapore, 427447. Produced under the
control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie,
Kotka, Finland, 48310. Made in China.

® Registered Trademark of Oy SVEN
Scandinavia Ltd. Finland.



KB-C3800W