

SVEN[®]
YOU WANT - WE CAN

Wireless Optical Mouse

USER'S MANUAL



RX-333
WIRELESS

www.sven.fi

Congratulations on purchasing the SVEN PC mouse!

Please read the following User's Manual carefully before connecting, operating or adjusting this product. Besides, please keep this Manual in a safe place for future reference.

COPYRIGHT

© 2014. SVEN PTE. LTD. Version 1.0 (V 1.0). This Manual and information contained in it are copyrighted. All rights reserved.

TRADEMARKS

All trademarks are the property of their legal holders.

NOTICE OF RESPONSIBILITY RESTRICTION

Despite the exerted efforts to make this Manual more exact, some discrepancies may occur. The information of this Manual is given on "as is" terms. The author and the publisher do not bear any liability to a person or an organization for loss or damages which have arisen from the information contained in the given Manual.

СОДЕРЖАНИЕ

1. SPECIAL FEATURES	2
2. PACKAGE CONTENTS	2
3. SYSTEM REQUIREMENTS	2
4. DESCRIPTION	3
5. INSTALLATION	3
6. TROUBLESHOOTING	6
7. TECHNICAL SPECIFICATIONS	6

Technical support: www.sven.fi

1. SPECIAL FEATURES

- Full-sized mouse
- BlueLED advanced optical technology
- Power saving wireless technology
- Ergonomic mouse shape
- 2.4GHz USB nano receiver included (range – up to 10 m)
- High-precision optical sensor
- Effective on most surfaces
- Additional navigation scroll wheel
- 800/1200/1600 dpi resolution switch
- Power on/off switch
- USB interface
- 2 AA type batteries*
- Soft Touch coating
- No drivers required for Windows XP/Vista/7/8

2. PACKAGE CONTENTS

- Optical mouse — 1 pc
- 2.4 GHz USB nano receiver — 1 pc
- AA type batteries — 2 pcs
- User's Manual — 1 pc
- Warranty card — 1 pc

3. SYSTEM REQUIREMENTS

- Windows XP/Vista/7/8.
- Free USB port.

*To be used with AA batteries.

4. DESCRIPTION

- ① Scroll wheel
- ② Additional scroll wheel for navigation
- ③ Resolution switch
- ④ on/off: Power on/off switch
- ⑤ Optical sensor
- ⑥ Battery compartment
- ⑦ Nano receiver
- ⑧ USB connector




Fig. 1. Top view




Fig. 2. Bottom view




Fig. 3. Nano receiver

5. INSTALLATION

- Open the cover of the mouse battery compartment ⑥, insert two AA type batteries into the battery compartment, matching the polarity, and close the cover of the battery compartment (see Fig. 4).
- Pull out the nano receiver ⑦ from the mouse (Fig. 5) and connect it to an available PC USB port without switching off the PC (Fig. 6).

- Turn on the mouse with the on/off switch ④ (the On position). To activate the mouse, press any button of the mouse or turn the scroll wheel. If the mouse is connected correctly, it will turn on automatically.




Fig. 4. Batteries installation



Fig. 5. Extraction of the receiver from the mouse case




Fig. 6. Receiver connection

- After finishing your work, turn off the mouse with the on/off switch ④ (the Off position). Then take the nano receiver out of the USB port and insert it back into the mouse. (Fig. 7).
- Do not place the receiver in a metal confined space (table drawer, box, safe), as a metal screen does not transmit radio signals.
- If the batteries run down, the mouse works in jerks. It means that the batteries should be replaced with new ones, as it is shown in Fig. 4. Always install only identical new batteries.




Fig. 7. Fitting the receiver into the mouse case

! Important

- ***This device meets the highest standards of energy conservation. Use the switch ④ on the bottom of the mouse to switch it on/off – it will help you extend the mouse battery life.***

6. TROUBLESHOOTING

Problem	Solution
The mouse doesn't work.	<ol style="list-style-type: none"> 1. Make sure that the nano receiver has been inserted into the USB port and its distance to the mouse is less than 10 m. 2. Check if the batteries have been installed correctly. 3. Replace the discharged batteries with new ones. 4. Check the position of the switch. Shift it to the necessary position if needed.
Batteries are in good order, but the mouse still does not work.	Install the software to coordinate the mouse and the receiver. Software can be downloaded from Support on www.sven.fi

7. TECHNICAL SPECIFICATIONS

Parameter, measurement unit	Value
OS compatibility	Windows XP/Vista/7/8
Type of mouse	Wireless 2.4 GHz
Resolution, dpi	800/1200/1600
Q-ty of buttons	3 + 1 (scroll wheel)
Interface	USB
Operating range, m	10
Additional scroll wheel for navigation	yes
Dimensions, mm	95 × 40 × 110
Weight, g	79

Notes:

- **Technical specifications given in this table are supplemental information and cannot give occasion to claims.**
- **Technical specifications are subject to change without notice due to improvement of SVEN production.**

Wireless Optical Mouse

SVEN[®]
YOU WANT – WE CAN



Модель: **RX-333 Wireless**

Импортер в России: ООО «СКАНДИТРЕЛ», 111024, РФ, г. Москва, ул. Авиамоторная, д. 65, стр. 1.

Уполномоченная организация в России:

ООО «РТ-Ф», 105082, г. Москва, ул. Фридриха Энгельса, д. 75, стр. 5.

Условия гарантийного обслуживания смотрите в гарантийном талоне или на сайте **www.sven.fi**.

Гарантийный срок: 12 мес. Срок службы: 2 года.

Производитель: «СВЕН ПТЕ. Лимитед»,

176 Джу Чиат Роуд, № 02-02, Сингапур, 427447.

Произведено под контролем «Свен Скандинавия Лимитед», 48310, Финляндия, Котка, Котолахдентие, 15. Сделано в Китае.

Manufacturer: SVEN PTE. LTD., 176 Joo Chiat Road, № 02-02, Singapore, 427447. Produced under the control of Oy Sven Scandinavia Ltd. 15, Kotolahdentie, Kotka, Finland, 48310. Made in China.

© Registered Trademark of Oy SVEN Scandinavia Ltd. Finland.

RX-333W